

Telephone Set JAŚMIN

Analog corded phone



Features:

- Phone Book for up to 125 items, each including a phone number and a name;
- CallerID list for up to 72 incoming call entries, each including a phone number and a name;
- Phonebook and CallerID entry can store up to a 22-digit phone number and 16-character name;
- DTMF and FSK CallerID support;
- Caller's name displayed on LCD, if his/her name entered into the Phonebook is combined with a phone number that matches a calling one, identified by the CallerID system;
- Calling phone number identified by the CallerID system can be saved in the Phonebook along with a caller's name added by you;
- Phonebook entries and other phone settings remain saved without batteries for a time necessary for replacing old batteries with new ones;
- Direct memory of 10 phone numbers;
- Indirect memory of 12 phone numbers;
- Buffer memory of up to 16 last dialed numbers, up to 16 digits each, for redialing purposes;
- 4-row LCD screen displaying a phone number, name, time and date, week day and a call time;
- Selectable number of digits of an area code and long distance access number from 0 to 5;
- Supports menu and on-screen messages in 8 main languages;
- PRIVATE CALL and UNAVAILABLE on-screen messages;
- New and repeated call icon indicator;
- All and new calls number display;
- Date and time display;
- Call time display;
- Speakerphone mode;
- Hold and music on hold function;
- Flash function;
- Pause function;
- BabyCall function;
- VIP function.



1. **Liquid Crystal Display (LCD)** – shows dialed and caller's number, menu, date, time, etc;
2. **UP key** – scrolls content displayed on LCD upwards and allow to view the CallerID list;
3. **DOWN key** – scrolls displayed content downwards and allows to view the CallerID list;
4. **DEL key** – deletes entries from the CallerID list or the Phonebook and is used to delete digits or characters, when in the entering or saving phone numbers mode
5. **SET/DIAL key** – serves to enter into the menu setting mode, to confirm a setting or for dialing numbers displayed on LCD;
6. **STORE key** – enables to save phone numbers in the memory or in the Phonebook;
7. **ABC key** – to view the Phonebook;
8. **FLASH key** – generates a timed-break for enabling call waiting or other services offered by a telecom operator;
9. **REDIAL key** – can be used to redial a last dialed number, to insert 3,6 second inter-digital pause during entering a phone number before its dialing, or to view a list of outgoing calls when in the on-hook mode;
10. **MEM key** – enables to initiate dialing phone numbers from indirect memory;
11. **MUTE key** – mutes microphone during conversation;
12. **HOLD key** – puts a phone call on hold with a music sent to the other party;
13. **SPK key** – enables speakerphone (hands-free) mode;
14. **VIP key** – assigns VIP status to a phone call entry when viewing the CallerID list
15. **M1, M2...M10 keys** – direct memory keys;
16. **Dialing keys** – serve for entering phone numbers and letters;
17. **VOL key** – adjusts speaker volume;
18. **NEW LED** – indicates a new call identified;
19. **IN USE LED** – indicates off-hook or speakerphone operation mode;
20. **HI/LO switch** – adjusts ringer volume to high (HI) or low (LO) level;
21. **P/T switch** – serves to set the pulse (P) or tone (T) dialing mode;
22. **Line jack** – to connect the phone to a line

